



Example 1



Description

1. Input the condition to initial step S0
2. Input the S0 and the divergent conditions of S20, S0 and S21
3. Input the S20
4. Input the S21
5. Input the convergence of S20 and S21
6. Input the S22


Example 2




Description

1. Input the condition to initial step S0
2. Input the S0 and the divergent condition of S20 and S22
3. Input the S20
4. Input the S21
5. Input the S22
6. Input the convergence of S21 and S22
7. Input the S23

Example 3



WinProladder



FP-07



Net0	ORG TO	M1924 S0
Net1	STP OUT FROM OUT TR AND TO LD TR AND TO	S0 Y0 S0 0 X1 S20 0 X4 S24
Net2	STP OUT FROM AND TO TO	S20 Y1 S20 X2 S21 S22
Net3	STP OUT	S21 Y2
Net4	STP OUT	S22 Y3
Net5	FROM FROM AND TO	S21 S22 X3 S23
Net6	STP OUT	S23 Y4
Net7	STP OUT	S24 Y5
Net8	FROM AND FROM AND ORLD AND TO	S23 X5 S24 X6 X7 S0
Net9	STPEND	


Description

1. Input the condition to initial step S0
2. Input the S0 and the divergences of S20 and S24
3. Input the S20
4. Input the S20 and the divergences of S21 and S22
5. Input the S21
6. Input the S22
7. Input the convergences of S21 and S22
8. Input the S23
9. Input the S24
10. Input the convergences of S23 and S24

8.5 Application Examples

Example 1 Grasp an object from tank A and put it in Tank B






Release claw
 Return to the left limit
 Return to the upper limit
 Turn the switch ON before moving to S20
 Stretch arm downward
 Move to S21 after stretching to the lower limit
 Claw grasps (since the SET instruction is used, Y4 should remain ON after departing from STP S21)
 Divergent into S22 after 1S
 Lift the arm up
 Divergent into S23 after reaching the upper limit
 Move arm to the right
 Divergent into S24 after moving to the right limit
 Stretch the arm downward
 Divergent into S25 after stretching to the lower limit
 Release claw
 Delay for 1S
 Transfer into S26 after 1S
 Lift the arm up
 Divergent into S27 after reaching the upper limit
 Move the arm to the left
 Divergent into S0 after moving to the left limit (a complete cycle)

```


ORG      M1924
TO       S0
STP      S0
OUT TR   0
OUT NOT  Y4
AND NOT  X1
OUT      Y0
LD TR    0
AND NOT  X2
OUT      Y2
FROM     S0
AND      X0
TO       S20
STP      S20
OUT      Y3
FROM     S20
AND      X3
TO       S21
STP      S21
EN SET   Y4
EN T0    100
TO       S22
Divergent into S22 after 1S
Lift the arm up
Divergent into S23 after reaching the upper limit
OUT      Y2
FROM     S22
AND      X2
TO       S23
STP      S23
OUT      Y1
FROM     S23
AND      X4
TO       S24
STP      S24
OUT      Y3
FROM     S24
AND      X3
TO       S25
STP      S25
EN RST   Y4
EN T1    100
TO       S26
Divergent into S26 after 1S
Lift the arm up
Divergent into S27 after reaching the upper limit
STP      S26
OUT      Y2
FROM     S26
AND      X2
TO       S27
Divergent into S0 after moving to the left limit (a complete cycle)
STP      S27
OUT      Y0
FROM     S27
AND      X1
TO       S0
STPEND
    
```

Example 2 Liquid Stirring Process




- Input Points: Empty limit switch X1
No liquid limit switch X2
Empty limit switch X3
Over-load switch X4
Warning clear button X5
Start button X6
Water washing button X7
- Warning Indicators: Empty dried material Y1
Insufficient liquid Y2
Empty stirring unit Y3
Motor over-load Y4
- Output Points: Dried material inlet valve Y5
Dried material inlet valve Y6
Liquid inlet valve Y7
Motor start electromagnetic valve Y8
Clean water inlet valve Y9
Finished product outlet valve Y10
- Weighing Output: CH0 (R3840)
- M1918=0

WinProladder



FP-07			
ORG	M1924	STP	S22
TO	S0	OUT	Y7
STP	S0	T1 PV: 800	
OUT TR	0	FROM	S21
AND NOT	X1	FROM	S22
SET	Y1	AND	T0
LD TR	0	AND	T1
AND NOT	X2	TO	S23
SET	Y2	STP	S23
LD TR	0	OUT TR	0
AND	X3	OUT	Y8
SET	Y3	LD TR	0
LD TR	0	T2 PV: 4500	
AND	X4	LD TR	0
SET	Y4	AND	X4
LD TR	0	OUT	Y4
AND	X5	STP	S24
RST	Y1	OUT TR	0
RST	Y2	T3 PV: 500	
RST	Y3	LD TR	0
RST	Y4	AND NOT	T3
FROM	S0	OUT	Y9
OUT TR	1	LD TR	0
AND	X6	T4 PV: 1500	
AND NOT	Y1	LD TR	0
AND NOT	Y2	AND NOT	T4
AND NOT	Y3	OUT	Y10
AND NOT	Y4	FROM	S23
TO	S20	AND	T2
LD TR	1	FROM	S24
AND	X7	AND	T4
AND NOT	Y3	ORLD	
AND NOT	Y4	TO	S25
TO	S24	STP	S25
STP	S20	OUT TR	0
OUT	Y5	AND	X3
FUN	17	OUT	Y10
	Sa:R3840	LD TR	0
	Sb:R0	AND TU	S25
FO	0	FUN	15DP
OUT	M0		D:R10
FO	1	FROM	S25
OUT	M1	AND NOT	X3
FROM	S20	TO	S0
LD	M0	STPEND	
OR	M1		
ANDLD			
TO	S21		
TO	S22		
STP	S21		
OUT	Y6		
T0 PV: 500			

Example 3 Pedestrian Crossing Lights




- ♦ Input Points: Pedestrian Push Button X0
Pedestrian Push Button X1

- ♦ Output Points: Road Red Light Y0
Road Amber light Y1
Road Green Light Y2
Pedestrian Crossing Red Light Y3
Pedestrian Crossing Green Light Y4


- ♦ M1918=0

● Pedestrian Crossing Lights Control Process Diagram



● Pedestrian Crossing Lights Control Program

WinProladder



FP-07

ORG	M1924	STP	S32
TO	S0	T4 PV:	100
STP	S0	FROM	S32
OUT	Y2	AND	T4
OUT	Y3	TO	S33
FROM	S0	STP	S33
LD	X0	OUT TR	0
OR	X1	OUT	Y4
ANDLD		LD TR	0
TO	S20	AND TU	S33
TO	S30	LD	OPEN
STP	S20	C1 PV:	6
OUT	Y2	LD TR	0
T0 PV:	3000	T5 PV:	100
FROM	S20	FROM	S33
AND	T0	OUT TR	1
TO	S21	AND NOT	C1
STP	S21	AND	T5
OUT	Y1	TO	S32
T1 PV:	500	LD TR	1
FROM	S21	AND	C1
AND	T1	AND	T5
TO	S22	TO	S34
STP	S22	STP	S34
OUT	Y0	OUT	Y3
T2 PV:	500	RST	C1
STP	S30	T6 PV:	100
OUT	Y3	FROM	S22
FROM	S30	FROM	S34
AND	T2	AND	T6
TO	S31	TO	S0
STP	S31	STPEND	
OUT	Y4		
T3 PV:	2000		
FROM	S31		
AND	T3		
TO	S32		

8.6 Syntax Check Error Codes for Step Instruction

The error codes for the usage of step instruction are as follows:

- E51 : TO(S0-S7) must begin with ORG instruction.
- E52 : TO(S20-S999) can't begin with ORG instruction.
- E53 : TO instruction without matched FROM instruction.
- E54 : To instruction must come after TO, AND, OR, ANDLD or ORLD instruction.
- E56 : The instructions before FROM must be AND, OR, ANDLD or ORLD
- E57 : The instruction after FROM can't be a coil or a function
- E58 : Coil or function must be before FROM while in STEP network.
- E59 : More than 8 TO# at same network.
- E60 : More than 8 FROM# at same network.
- E61 : TO(S0-S7) must locate at first row of the network.
- E62 : A contact occupies the location for TO instruction.
- E72 : Duplicated TO Sxx instruction.
- E73 : Duplicated STP sxx instruction.
- E74 : Duplicated FROM sxx instruction.
- E76 : STP(S0~S7) without a matched STPEND or STPEND without a matched STP(S0~S7).
- E78 : TO(S20~S999), STP (S20~S999) or FROM instructions come before or without STP(S0~S19).
- E79 : STP Sxx or FROM Sxx instructions come before or without TO Sxx.
- E80 : FROM Sxx instruction comes before or without STP Sxx.
- E81 : The max. level of branches must ≤ 16 .
- E82 : The max. no. of branches with same level must ≤ 16 .
- E83 : Not place the step instruction with TO->STP->FROM sequence.
- E84 : The definition of STP# sequence not follow the TO# sequence.
- E85 : Convergence do not match the corresponding divergence.
- E86 : Illegal usage of STP or FROM before convergent with TO instruction.
- E87 : STP# or FROM# comes before corresponding TO#.
- E88 : During this branch, STP# or FROM# comes before the corresponding TO#.
- E89 : FROM# comes before corresponding TO# or STP#.
- E90 : Invalid To# usage in the simultaneous branch.
- E91 : Flow control function can not be used in the step ladder region.